

PARTS

Instructions Heavy Duty Leak Diverter



LEAK DIVERTER



DRAIN CUP



HOSE FITTING



QUICK CONNECT (optional)



HOSE (optional)



SLACK ADJUSTER (optional)



CLIP (optional)



ROPE (optional)



CAP

1



Remove all components from packaging, unfold and locate DRAIN CUPS. (There may be up to 3 DRAIN CUPS, depending on the size of the DIVERTER.) For shipping, the DRAIN CUPS are in an inverted position. Push up on the DRAIN CUP until it turns inside out. Now water will flow freely into opening.

6



Attach CLIP to ROPE on the underside of the SLACK ADJUSTER. Attach CLIP to one of the GROMMETS on the DIVERTER. Make sure the DIVERTER faces down, away from drip (hose connection faces toward floor).

2



Push black HOSE FITTING into bottom of DRAIN CUP until snug. Once inserted, tighten threaded ring to secure HOSE FITTING to DRAIN CUP. Do not over-tighten ring.

7



Secure/tie ROPE (without knot) to a sturdy beam, pipe, hook or object that can hold the weight of the DIVERTER and any water that pools inside.*

3



If your DIVERTER came with the optional QUICK CONNECT, separate the two pieces and attached the male end of the QUICK CONNECT into the HOSE FITTING. Attach female side onto HOSE and set to side. It is easier to install DIVERTER without the hose being attached.

Repeat steps 4-7 for other GROMMETS on DIVERTER. Do not tighten SLACK ADJUSTERS until all ropes have been secured.

4



Pull one end of ROPE through hole of SLACK ADJUSTER and make a knot. Make sure SLACK ADJUSTER is in proper positioning. The bend should be on top, which is the same side as knot.

After all ropes have been tied down, use SLACK ADJUSTERS to tighten ROPES so that water can flow freely toward DRAIN CUPS.

5



Insert other end of ROPE through the second hole of the SLACK ADJUSTER. Do not tie a knot at this time.

9



Attach the HOSE to DRAIN CUP (or reconnect QUICK CONNECT with hose already in place). Insert other end of hose into a bucket, drain or anything else that can contain the water coming down from DIVERTER. Monitor the movement of water, so overflow or pooling on floor doesn't occur.

10



GO GRAILEY HEAVY DUTY LEAK DIVERTERS are transparent for observing blockages near the DRAIN CUP or any pooling water. If you see that the water is not flowing freely, adjust ROPES so water flows into DRAIN CUP and down hose. Place included CAPS onto any unused DRAIN CUPS.

*Grailey Materials, LLC holds no responsibility for damages caused by improper handling, hanging or use of this products. Use of this item is at your own risk.

