

PARTS



Instructions Umbrella Leak Diverter



1 Remove all components and slide off reusable storage COVER. You can store the UMBRELLA LEAK DIVERTER in the COVER when not in use.



6 Open UMBRELLA and adjust until it's balance on the object it will hang from.



2 For shipping, the DRAIN CUP is in an inverted position. Push up on the DRAIN CUP until it turns inside out. Now water can flow freely into CUP.



7 Attach the HOSE to DRAIN CUP (or reconnect QUICK CONNECT with hose already in place). Insert other end of hose into a bucket, drain or anything else that can contain the water coming down from DIVERTER. Monitor the movement of water, so overflow or pooling on floor doesn't occur.



3 Push black HOSE FITTING into bottom of DRAIN CUP until snug. Once inserted, tighten threaded ring to secure HOSE FITTING to DRAIN CUP. Do not over-tighten ring.



8 GO GRAILEY UMBRELLA LEAK DIVERTERS are transparent for observing blockages near the DRAIN CUP. If you see that the water is not flowing freely, clear any blockage so water moves into DRAIN CUP and down hose.



4 If your DIVERTER came with the optional QUICK CONNECT, separate the two pieces and attached the male end of the QUICK CONNECT into the HOSE FITTING. Attach female side onto HOSE and set to side. It is easier to install DIVERTER without the hose being attached.



5 HOOK UMBRELLA DIVERTER to any secure object that will be able to hold the weight of the DIVERTER and any water that pools inside.*

ALTERNATIVE HANGING

You can use the reusable storage COVER to assist with the installation of your Go Grailey Umbrella Leak DIVERTERS in hard to reach places.

- Carefully cut the bottom of the COVER straight across so that the whole DIVERTER will be able to slide out. Be careful not to cut DIVERTER.
- Follow instructions 2 - 3 (to left).
- Attach hose through bottom of COVER.
- Hang Umbrella.
- Once hung, pull COVER off and remove at the bottom of the hose.
- Run hose into a bucket, drain or anything else that can contain the water.

*Grailey Materials, LLC holds no responsibility for damages cause by improper handling, hanging or use of this products. Use of this item is at your own risk.

